


Solar Flagpole LED Deluxe

Battery Replacement Instructions



1. Remove Face Screws



2. Remove Faceplate



3. Remove Gasket and move Solar Panel without disconnecting or breaking any wires

4. Remove and Replace Battery

5. Put the solar panel in place

6. Put gasket in place

7. Put faceplate on and insert screws
(Do not over tighten)

